

When installing this type of floor heating, the tubes using Tacker staples must be mounted on 20 or 30mm thick insulation. This system is ideal when you want to provide a large area of floor heating and floor insulation. In order to expand the floor and shrink, it is important that there is an edge insulation placed against all the walls.





